

GEN 8 DIGITAL PANEL GUIDE

RECOMMENDED SETTINGS

- AES** Off
- Temperature** Showers: 50°C
Bathtubs: 65°C

Without power, panel will retain settings for 48 hours.



CURRENT TEMP

This is the actual tank temperature. It may differ from the setting temperature.



RECOMMENDED TEMPERATURE

Use settings below to save energy.

- Showers: 50°C
- Bathtubs: landed homes: 65°C



✗ **Avoid bacteria.** Do not set below 50°C

Fault indicator: Contact AOS



INSTANT HOT WATER

Even with 1 red bar, you can shower immediately.



AES: AUTO TIMER

AES is for cold climates. Disable for Singapore.



MAINTENANCE MONITOR

Press and hold to test.

- P1:** tank is clean
- P2:** maintain soon




MAINTENANCE PROMPT

If indicator is on, maintenance is due.



CLOCK AND TIMER

- To save more energy, **disable the timer.** It is better to turn off the heater when not in use.
- Timer demo: www.aosbath.com/clock



TEMPERATURE INDICATOR

- **Red:** hot
- **Yellow:** warm
- **Green:** cold



POWER

Switch off your heater after use. Use main heater switch to power off.

