

# INTEGRATED HPI HEAT PUMP PANEL GUIDE

## RECOMMENDED SETTINGS

<b>AES</b>	Off
<b>Temperature</b>	65°C
<b>Timer</b>	Off, leave heater on
<b>Mode</b>	Efficiency

## TEMP. SETTINGS

Set to 65°C to save energy.



**✗ Avoid bacteria.**  
Do not set below 50°C

## TEMP. INDICATOR

- **Red:** hot
- **Yellow:** warm
- **Green:** cold

## Save time:

Have 3 red bars or more?  
You can shower immediately.



## SPEED HEATING

Get hot water in 15 minutes. Uses 100% electricity instead of heat pump.



## POWER

Do not switch off your heat pump. Power off only if vacationing for over 3 days.



## Memory

Without power, the panel will retain settings for 48 hours.



## ACTUAL TEMPERATURE

Measures internal tank temperature. It may differ from the setting temperature.



## AES: AUTO TIMER

AES is for cold climates. Do not activate in Singapore.



## MODE

Efficiency: 510 watts  
Hybrid: 3000 watts

Not in use in Singapore



## TIMER

Demo video:  
[www.aosbath.com/clock](http://www.aosbath.com/clock)

