Gen 6 Digital Panel Guide

aosbath
Trusted Water Heater Specialists

USE THESE SETTINGS

Mode Multiple

Set Temp. Showers: 50°C
Bathtubs: 65°C

Heating Light
When light is on, tank is actively heating.

Set Temperature
For Singapore:
Showers: 50°C
Bathtubs: 65°C

Avoid bacteria.
Do not set below 50°C.

Actual temperature
average tank temp.

Heater mode
For Singapore, use **Multiple**

With Single or Standard mode, you will get less hot water.

Clock and Timer
To save more energy, **don't use a timer**.

It is best to turn off the heater when not in use.

Timer demo:
www.aosbath.com/clock

Temperature Bars
Red: hot
Yellow: warm
Green: cold

Save time: 2 red bars means you can shower now.

Instant Speed Heat
In multiple mode, this is an auto function.

When heater is speed heating, this light will come on.

Up-Down Keys
Use these to set your tank temperature

Power
At main heater switch, power off after use.
Without power, panel keeps settings for 48 hours.