



Gen 6 Digital Panel Guide

Best settings for SG

Mode Multiple
Set Temp. Showers: 50°C
Bathtubs: 65°C


 **Heating light**
When light is on, tank is heating.

 **Set temperature**
For Singapore:
Showers: 50°C
Bathtubs: 65°C


 **Avoid bacteria.**
Do not set below 50°C.


 **Actual temperature**
average tank temp.

 **Heater mode**
For Sg: use **Multiple**
Single / Standard: less hot water.

 **Clock and timer**
To save more energy,
don't use timers.


Timer demo:
www.aosbath.com/clock


 **Up-down keys**
Use these to set tank temperature.

 **Heater switch**
Turn off heater here when not in use. When off, panel keeps settings for 48 hours.



Temperature bars
Red: hot
Yellow: warm
Green: cold
Save time: 2 red bars means you can shower now.

 **Instant heat**
In multiple mode, this is an auto function.

 When heater is speed heating, this light will come on.